

## 8155 PPI With Study Card



**Product Categories:** [Electronics](#), [Engineering Equipment](#), [Microprocessor & Micro-controller Lab](#), [Microprocessor & Micro-controller Lab](#), [Study Cards](#), [Study Cards](#)

**Product Page:** <https://www.labappara.com/product/8155-ppi-with-study-card/>

### Product Description

#### 8155 PPI With Study Card

Compatible with  $\mu$ Processor /  $\mu$ Controller Kits. Jumper Selectable I/O addresses  
Demo programs of all modes available. Compatible programs based on different kits supported available.

RST5.5, RST6.5, RST7.5 are provided onboard for interrupt driven modes. Using 8155, all possible modes can be experimented.

PA0-PA7, PB0-PB7, PC0-PC7 LED indicators and test lug inputs with handshake signals.

User links and lugs provided for inputs with their legends.

Experiments for both polled and interrupt driven data transfer is possible with links for 8085 interrupts.

Separate key is provided to give manual clock for 8155 times I/P's.

Supplied in a attractive wooden cabinet