

## DUAL OUTPUT 30-0-30 V DC /5 Amps

**Product Categories:** [DC Regulated Power Supply Single/Dual Channel](#), [DC Regulated Power Supply Single/Dual Channel](#), [Electronics](#), [Engineering Equipment](#)

**Product Page:**

<https://www.labappara.com/product/dual-output-30-0-30-v-dc-5-amps/>

### Product Description

DUAL OUTPUT 30-0-30 V DC /5 Amps

Dual Output DC Regulated Power Supply are constant Voltage & Constant Current type supplies , have high regulation for Load & Line Voltage variation . The supply can be use in independent & tracking mode . The supply are protected against short circuit & over load . The output current can be controlled to any value from 0 to maximum

INPUT VOLTAGE	:	230V $\pm$ 10% AC 50 Hz
LOAD REGULATION CV	:	$\pm$ 0.05 % $\pm$ 3mV From no load to full load
LOAD REGULATION CC	:	0.05% 1mA From no load to full load
LINE REGULATION CV	:	$\pm$ 0.01 % $\pm$ 3mV for 10% variation input voltage
LINE REGULATION CC	:	0.01% 1mA for 10% variation input voltage
OPERATING MODE	:	Independent & Tracking mode
RIPPLE	:	Less than 1 mV
METER	:	Four Digital meters to monitor the output
voltage & current		voltage & current of
A & B Supply		
ACCURACY	:	1% + 1 Digit +
PROTECTION	:	Against short circuit & over load