

Power Factor Meter 1P 1E (144X144)



Product Categories: [Electronics](#), [Engineering Equipment](#), [Panel Mounted \(Analog\)](#), [Panel Mounted \(Analog\)](#)

Product Page:

<https://www.labappara.com/product/power-factor-meter-1p-1e-144x144/>

Product Description

Power Factor Meter 1P 1E (144X144)

Description:-

- Powerfactor are based on dynamometric principle.
- Dynamometric instruments for measurement of absolute power in single phase systems.

Specification:-

Movement Type	:	Current coil in series of load & pressure coil across the load. Work on "Air cored Electro-Dynamometric" principle.
Range	:	Current (A) : 1A or 5A Voltage (V) : 110V or 440V
Accuracy	:	2° Phase Angle
Size	:	144X144 mm