

Power Factor Meter 3P 3E (96X96)



Product Categories: [Electronics](#), [Engineering Equipment](#), [Panel Mounted \(Analog\)](#), [Panel Mounted \(Analog\)](#)

Product Page:

<https://www.labappara.com/product/power-factor-meter-3p-3e-96x96/>

Product Description

Power Factor Meter 3P 3E (96X96)

Description:-

- Powerfactor are based on Dynamometric principle.
- Powerfactor Meters 3 Element Dynamometer Type for 3 Phase, 3 Wire & 4 Wire Loads.

Specification:-

Movement Type : Current coil in series of load & pressure coil across the load. Work on "Air cored Electro-Dynamometric" principle.

Range : Current (A) : 1A or 5A
Voltage (V) : 110V or 440V

Accuracy : 2° Phase Angle

Size : 96x96mm